

## FUNCTION DESCRIPTION

It is used to transfer materials from the incoming tray or grab materials from the upstream line body and puts them into the empty tray.

Model	Axis Motion Repeatability	Max Tray Size	Manipulator Movement Range
M7116925-00	±0.03mm	400*600mm	Customized to tray

## ADAPTIVE UNIT

